Tiandy Network Video Camera Series



ISO 9001:2008 ISO 14001:2004

Thank you for choosing our products.

Please read the User Manual carefully before using this product.

This user manual will provide you with instructions for correct installation and operation.

Safety Instruction

These instructions are intended to ensure that user can use the product correctly to avoid danger and property loss. Please carefully read this guidance and keep it for future reference before operating the device. The manual is designed to instruct users to facilitate installation. The interface in details depends on the exact product.

The latest version will be updated regularly according to the software and hardware improvement of our product. Updated information will be updated in the latest version of this manual without prior notice.

The precaution measure is divided into "Warnings" and "Cautions"



Warnings

Follow these safeguards to prevent serious injury or death.

- 1. Input voltage should meet both the SELV (Safety Extra Low Voltage)
- 2. Contact the distributor for abnormal operation. Do Not disassemble or modify the devices in any way.
- 3. Moisture must be avoided for indoor devices in case of fire and electric shock.
- 4. Install the equipment on the ceiling to ensure that it can withstand at least 4 times the weight of the equipment.
- 5. Moisture must be avoided for indoor devices in case of fire and electric shock.



Cautions

Follow these precautions to prevent potential injury or material damage.

- 1.Original package must be used for shipment and management to avoid high pressure, high vibration and imprisonments
- 2. Avoid direct contact with image sensor. Cover the dust cap while not operating.
- 3.Do not aim the camera at the extra bright places (light, sunlight, laser) in case of affecting the endurance of CMOS at the same time.
- 4.Do not place the camera in extremely hot, cold, dusty or damp locations, and do not expose it to high electromagnetism radiation.
- 5.To avoid heat accumulation, good ventilation is required for operating environment.
- 6. Ensure that the installation location is kept at a sufficient distance from the surrounding electromagnetic sensitive equipment to prevent electromagnetic interference.
- 7.Keep the camera away from liquid while on using. Original package during shipment is strongly recommended.
- 8. Any replacement of the device battery or the use of a mismatched type may cause irreversible damage to the device.
- 9. Modify the default login password when first login the device to avoid the loss caused by weak password.
- 10.When the Micro SD is used, it is recommended to use a special video surveillance 11.Micro SD card to avoid after sales maintenance arising from the rapid damage of ordinary Micro SD cards.

Quick Operation

Device Activation

• Enter default IP address: 192.168.1.2 in the address bar of the IE, and then the login interface will appear as shown in the Figure 1.



Figure 1. Login Interface

 When using the camera for the first time, you must activate the device and set a login password to log in and use it normally. To protect your personal privacy and corporate data and avoid cybersecurity issues with the product, it is recommended to set a high-strength password that complies with security standards.




Figure 2. Device Activation Interface

• Input new password according to the prompt message, then click the button "Save", and a prompt box will pop up as shown in Figure 3.





Figure 3. Prompt Box

• Click the "OK" button, then the login screen will be refreshed. After inputting the username and the new password, you will enter the preview interface.

• If it's your first time to use this product, you need to download and install the plug-in according to the prompt message, as shown in

Figure 4.



• Open the IE browser again after successful installation, and input the correct username and password to enter the preview interface. For detailed usage, please visit the website (http://en.tiandy.com/)

•

Быстрые операции

Активация устройства

• Введите IP-адрес устройства по умолчанию в адресной строке браузера IE: 192.168.1.2, после чего появится интерфейс входа в систему, как показано на рис. 1.



•При первом использовании камеры необходимо активировать устройство и установить пароль для входа, чтобы войти в систему и использовать её в обычном режиме. Для защиты вашей личной конфиденциальности и корпоративных данных, а также предотвращения проблем с кибербезопасностью продукта рекомендуется установить высоконадежный пароль, соответствующий стандартам безопасности.




Рис. 2 Интерфейс активации устройства

 Введите новый пароль в соответствии с подсказкой, нажмите кнопку «Сохранить», после чего появится всплывающее окно, как показано на рис. 3.




Рис. 3 Всплывающее окно

- Нажмите кнопку «Подтвердить», страница входа обновится. Введите имя пользователя и новый пароль, а затем войдите в интерфейс предварительного просмотра.
- При использовании данного продукта впервые, Вам необходимо загрузить и установить плагин в соответствии с инструкциями, как показано на рис. 4.



• После успешной установки плагина откройте браузер снова и введите правильное имя пользователя и пароль, чтобы войти в интерфейс предварительного просмотра. Чтобы получить подробную информацию, пожалуйста, войдите на официальный сайт (http://en.tiandy.com/) для загрузки.


Hızlı İşletim Cihazı Etkinleştir

IE tarayıcısının adres çubuğuna cihazın varsayılan IP adresini girin: 192.168.1.2, giriş arayüzü, Resim 1'de gösterildiği gibi görünecektir.




Resim 1 Giriş Arayüzü

Kamerayı ilk kez kullanırken, normal şekilde giriş yapmak ve kullanmak için cihazı etkinleştirmeli ve bir giriş şifresi belirlemelisiniz. Kişisel gizliliğinizi ve kurumsal verilerinizi korumak ve ürünün siber güvenlik sorunlarını önlemek için güvenlik standartlarına uygun yüksek güvenlikli bir şifre belirlemeniz önerilir.



Resim 2 Etkinleştirme Arayüzü

İstem bilgilerine göre yeni şifreyi girin, "Kaydet" düğmesini tıklayın,
 Resim 3'te gösterildiği gibi bir istemi penceresi açılır.



Resim 3 İstem Arayüzü

- "Onay" düğmesini tıklayın, giriş sayfası yenilenecektir, kullanıcı adını ve yeni şifrenizi girerek önizleme arayüzünü açabilirsiniz.
- Bu ürünü ilk kez kullanıyorsanız, eklentiyi Resim 4'te gösterildiği gibi indirip yüklemeniz gerekir.



 Eklenti başarıyla yüklendikten sonra, tarayıcıyı tekrar açın ve doğru kullanıcı adını ve şifreyi girerek önizleme arayüzüne girin. Ayrıntılı işlem bilgilerine ulaşmak için lütfen resmi web sitesi (http://en.tiandy.com/) giriş yapın.

التشغيل بالسرعة

1 تنشيط الجهاز

أدخل عنوان IP الافتراضي للجهاز في شريط العناوين الخاص بـ 192.168.1.2 في شريط العنوان للمستعرض وستظهر واجهة تسجيل الدخول، كما هو موضح في الرسم 1 التالي.



الرسم 1 واجهة تسجيل الدخول

عند استخدام الكاميرا لأول مرة، يجب تنشيط الجهاز وتعيين كلمة مرور تسجيل الدخول لتتمكن من الدخول و استخدامها بشكل طبيعي. لحماية خصوصيتك الشخصية وبيانات الشركة وتجنب مشكلات أمن الإنترنت للمنتج، يُنصح بتعيين كلمة مرور قوية تتوافق مع معايير الأمان



الرسم 2 واجهة تنشيط الجهاز


أدخل كلمة مرور جديدة حسب المعلومات التوجيهية، انقر فوق الزر"حفظ" وستظهر واجهة التوجيه، كما هو موضح في الرسم 3.

التقعيل تم يتجاح, الرجاء اعادة تسجيل الدخول


الرسم 3 واجهة التوجيه


انقر على زر "تأكيد" وسيتم تحديث صفحة تسجيل الدخول، وإدخال اسم المستخدم وكلمة المرور الجديدة، وستدخل إلي شاشة المعاينة.


إذا كنت تستخدم هذا المنتج لأول مرة، فستحتاج إلى تنزيل وتثبيت المكون الإضافي حسب معلومات واجهة التوجيه، كما هو موضح في الرسم 4.





بمجرد تثبيت المكون الإضافي بنجاح، افتح المتصفح مرة أخرى، وأدخل اسم المستخدم وكلمة المرور الصحيحة، وستدخل واجهة المعاينة. لمزيد من المعلومات حول كيفية استخدامه، يرجى زيارة الموقع الرسمي . (http://en.tiandy.com) لتحميله,
















































































Waterproof accessories

*2



Disclaimer

- 1. The company has tried its best to ensure the completeness and accuracy of the contents contained in the Manual. For any doubt or dispute, please refer to the company's final explanation.
- 2. The company will keep the contents contained in this Manual up-to-date in accordance with product enhancements and will periodically improve or update the products or procedures described in this Manual. The updated contents will be reflected in the latest version of this Manual without prior notice.
- 3. The contents contained in this Manual are for reference and guidance only for users. It is not guaranteed to be exactly the same with the real product. The real product shall prevail.
- 4. The parts, components and accessories mentioned in this Manual are for illustration purposes only and do not represent the configurations of your purchased model.

WARRANTY CARD

Thank you for choosing our products. This warranty card is our company's solemn commitment to you, and based on this, the company provides you with standard warranty services. It is strongly recommended that you read the instructions carefully before using the product and operate it correctly.

Warranty Policy

The warranty applies with the warranty card supplied.

After-sales Service Policy

This warranty is applicable to the product from the date of purchase, but the official original purchase certificate shall be provided.

If the official original purchase certificate cannot be provided or the record (date, commodity name) is not clear, the company will define the warranty period based on the product information.

Warranty Services

According to the national regulations, users enjoy the warranty services for the quality problems within the warranty period.

The followings shall not be covered by the warranty:

- · Exceeding one-year warranty
- Physical damage due to improper use or storage
- Failure or damage caused during transport, loading/unloading or handling
- Repair or modification by non-professionals
- Failure or damage caused by negligence, violation of operation rules or misoperation
- Failure or damage caused by force majeure factors (Fire, earthquake, lightning strike)
- No warranty over accessories such as fuse and battery
- Products not maintained by the company

7×24 high-quality service

The company reserves the right of final evaluation of product failure

